

CALENTADORES A GAS – JUNKERS

CASQUILLOS – REGULADOR - SELECTOR

CA450202



REGULADOR CAUDAL CALENTADOR JUNKERS
ORIGINAL 87074020210

CA450210



CASQUILLO REGULADOR AGUA JUNKERS
ORIGINAL 87034041170

CA450211



REGULADOR CAUDAL JUNKERS 10 L. W-WR
ORIGINAL 87085002500

CA450217



ESTABILIZADOR DE CAUDAL JUNKERS
ORIGINAL 87074020150

CA450220



SELECTOR CAUDAL CALENTADOR JUNKERS
5 L. ORIGINAL 87085002420

CA450222



CASQUILLO CALENTADOR JUNKERS ORIGINAL
87003061870

CA450227



REGULADOR CAUDAL CALENTADOR JUNKERS
WR250-75 6 K ORIGINAL 87085002850

CA450229/30/34



SELECTOR CAUDAL CALENTADOR JUNKERS
CA450229 – WR-WRD 11 L. 87085003320
CA450234 – WR-WRD 14 L. 87085003340
CA450230 – WR-WRD 18 L. 87085003040

CALENTADORES A GAS – JUNKERS

CASQUILLOS – REGULADOR - SELECTOR

CA450231



SELECTOR CAUDAL CALENTADOR JUNKERS
MINI MAX 6 L. ORIGINAL 87085002670

CA450237



SELECTOR CAUDAL CALENTADOR NECKAR
WN5-6 2KE ORIGINAL

CA452005



JUNTA SELECTOR CAUDAL CAL. JUNKERS
ORIGINAL 87002050230
(bolsa 10 unid.) Ø EXT. 18mm Ø INT. 13mm

CA452201



CASQUILLO CALENTADOR JUNKERS ANT.
ORIGINAL 87003060980

CA452202



CASQUILLO CALENTADOR JUNKERS
COMPLETO ORIGINAL 87003061140
