


CALENTADORES A GAS – JUNKERS – MANDOS

CA450205




CONJUNTO MANDOS CALENTADOR JUNKERS
ORIGINAL 87020002180*

CA450213



MANDO GAS CALENTADOR JUNKERS W / WR
ORIGINAL EJE CORTO 87020002340

CA450219



MANDO GAS CALENTADOR JUNKERS W / WR
ORIGINAL EJE LARGO 87020002350

CA450225



MANDO SELECTOR CAUDAL CALENTADOR
JUNKERS WRD ORIGINAL 87020002940

CA450228



MANDO GAS CALENTADOR JUNKERS WRD
ORIGINAL 87020002960

CA450236



MANDO SELECTOR CAUDAL CALENTADOR
NECKAR WN ORIGINAL

CA450218



PLACA GUIA + PALANCA CALENTADOR
JUNKERS/NECKAR ORIGINAL 87010003410

CA450238



CAJA POSTERIOR PLACA GUIA CALENTADOR
JUNKERS ORIGINAL